



■ GPF042-L1

輸出端(output)




輸入端(input)





■ GPF042-L2

輸出端(output)




輸入端(input)





■ GPF060-L1

輸出端(output)




輸入端(input)





■ GPF060-L2

輸出端(output)




輸入端(input)





■ GPF080-L1

輸出端(output)




輸入端(input)





■ **GPF080-L2**

輸出端(output)




輸入端(input)





■ GPF090-L1

輸出端(output)




輸入端(input)





■ GPF090-L2

輸出端(output)





輸入端(input)




■ GPF120-L1

輸出端(output)





輸入端(input)




■ GPF120-L2




輸出端(output)



輸入端(input)




■ GPF160-L1



■ GPF160-L2

輸出端(output)



輸入端(input)

