




■ GPL042-L1

輸出端(output)




輸入端(input)




■ GPL042-L2

輸出端(output)





輸入端(input)




■ GPL060-L1

輸出端(output)





輸入端(input)




■ GPL060-L2

輸出端(output)




輸入端(input)




■ GPL080-L1

輸出端(output)





輸入端(input)




■ GPL080-L2

輸出端(output)





輸入端(input)




■ GPL090-L1

輸出端(output)





輸入端(input)




■ GPL090-L2

輸出端(output)





輸入端(input)




■ GPL120-L1

輸出端(output)





輸入端(input)




■ GPL120-L2

輸出端(output)





輸入端(input)




■ GPL160-L1

輸出端(output)





輸入端(input)



■ GPL160-L2

輸出端(output)



輸入端(input)

